




Frame Assembly Instructions

Side

Front

Top





Hex nut 1/4-20



Camera adapter



Stud 3/8-24 x 1"



Flat Washer



Lock Washer 3/8"



Screw 3/8-24 x 3/4"

